




Fan Replacement for MSA/WSA 8200 Model



Loosen thumbscrew indicated by the arrow.



Hold the thumbscrew and slide the panel left and remove panel.



Remove the fan by pulling the tab on either side of the fan.

Replace the panel when done.